

# PARTS LIST

BC2621H-RS-02

## CONTENTS


1. MAIN BODY .....	1 ~ 2
2. GEARCASE.....	3 ~ 4
3. ENGINE .....	5 ~ 8
4. CARBURETOR, FUEL TANK .....	9 ~ 12
5. ACCESSORIES .....	13 ~ 14

2014. 03.




P/N 523779

1. BC2621H-RS-02  
MAIN BODY




Ref. No.	Part No.	Part Name	Q'ty	Remarks
1-1	364128	BC2621H-RS-02	1	
1-2	215512	Clutch Case Ass'y	1	Incl.3-9
1-3	214592	Bearing Case	1	
1-4	214161	Bearing	2	#6000ZZ
1-5	054676	Snap Ring	1	#26
1-6	214162	Buffer	1	
1-7	214163	Washer	1	
1-8	092033	Screw	4	M5x15
1-9	214593	Driveshaft Tube Adapter	1	
1-10	261246	Cap Screw	1	M5x25
1-11	054677	Clutch Drum	1	
1-12	219268	Driveshaft Ass'y	1	
1-13	218711	Driveshaft Tube	1	
1-14	215532	Shaft Grip	1	
1-15	215533	Hanging Bracket Ass'y	1	Incl.16
1-16	261762	Cap Screw	1	M5x14
1-17	216935	Bracket Ass'y	1	Incl.18
1-18	261246	Cap Screw	6	M5x25
1-19	233599	Label	1	BC2621H-RS
1-20	223188	Label	1	
1-21	261250	Cap Screw	4	M5x20
1-22	226501	Handle Ass'y-Left	1	Incl.23,24
1-23	226502	Handle	1	
1-24	226503	Grip	1	
1-25	232081	Handle Ass'y-Right	1	Incl.26,27
1-26	223714	Handle	1	
1-27	232082	Throttle Trigger	1	
1-28	231264	Label	1	111dBA
1-29	232086	Safety Cover Ass'y	1	Incl.30-36
1-30	231252	Safety Cover Ass'y	1	Incl.31,32
1-31	227819	Bracket	1	
1-32	221580	Screw	1	4x8
1-33	232087	Bracket Ass'y	1	Incl.34-36
1-34	227822	Bracket	1	
1-35	220632	Cap Screw	2	M6x30
1-36	231704	Washer	2	6x13x1.0
1-37	231882	String Cutter Ass'y	1	Incl.38-40
1-38	230747	String Cutter	1	
1-39	261250	Cap Screw	1	M5x20
1-40	228325	Nut	1	
1-41	230748	Cover Extention	1	
1-42	220533	Hanging Strap Ass'y	1	Incl.43
1-43	231657	Hook	1	

2. BC2621H-RS-02  
GEARCASE




Ref. No.	Part No.	Part Name	Q'ty	Remarks
2-1	231880	Gearcase Ass'y	1	Incl.2-17
2-2	225960	Gearcase	1	
2-3	234109	Bolt	1	M8x8
2-4	227990	Bearing	1	#608
2-5	228416	Gear Set	1	
2-6	219087	Cap Screw	1	M5x10
2-7	227991	Bearing	1	#6001DDU
2-8	055185	Snap Ring	1	#28
2-9	227992	Bearing	1	#609
2-10	227993	Bearing	1	#609Z
2-11	228477	Snap Ring	1	#9
2-12	140270	Snap Ring	1	#24
2-13	261246	Cap Screw	1	M5x25
2-14	212986	Boss Adapter	1	
2-15	140275	Clamping Washer	1	
2-16	215547	Stabilizer	1	
2-17	215610	Bolt	1	M8x22,Counterclockwise

3. BC2621H-RS-02  
ENGINE



Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-1	858928	Engine	1	CE260/12
3-2	283734	Cylinder	1	
3-3	283783	Gasket	1	
3-4	261250	Cap Screw	4	M5x20
3-5	269144	Insulator	1	New gasket required
3-6	267049	Gasket	1	
3-7	265924	Cap Screw	2	M5x25
3-8	282208	Muffler Ass'y	1	Incl.9-12
3-9	282209	Muffler Comp.	1	
3-10	267056	Spark Arrester	1	
3-11	268171	Muffler Tail	1	
3-12	265107	Cap Screw	2	M4x10
3-13	284071	Holder	1	
3-14	283940	Gasket	1	
3-15	266402	Cap Screw	2	M5x55
3-16	281435	Under Cover	1	
3-17	267191	Cap Screw	1	M5x16
3-18	286707	Top Cover Ass'y	1	Incl.19-22
3-19	281434	Top Cover	1	
3-20	286300	Knob	1	
3-21	261020	Spacer	1	
3-22	261734	Snap Ring	1	#5
3-23	289582	Crankcase	1	
3-24	280488	Bearing	2	PPL 6001
3-25	261492	Oil Seal	1	ISCD12287
3-26	261386	Oil Seal	1	ISCD12227
3-27	055185	Snap Ring	1	#28
3-28	261612	Cap Screw	3	M5x30
3-29	281442	Screen	1	
3-30	268247	Piston	1	
3-31	261496	Piston Ring	2	(2)Required
3-32	261497	Piston Pin	1	
3-33	261037	Bearing,Needle	1	KBK8x11x11.8x1
3-34	261576	Clip,Piston	2	
3-35	265197	Crankshaft/Conn.Rod Ass'y	1	
3-36	267327	Clutch Ass'y	1	Incl.37,38
3-37	267342	Clutch Shoe	2	(2)required
3-38	267345	Spring,Clutch	1	
3-39	264505	Bolt	2	
3-40	261189	Washer	2	6x16.5x1.2
3-41	261777	Wave Washer	2	
3-42	281433	Fan Cover	1	
3-43	261250	Cap Screw	4	M5x20
3-44	283729	Magneto Ass'y	1	Incl.45-53
3-45	268253	Rotor/Fan	1	


3. BC2621H-RS-02  
ENGINE






Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-46	283705	Ignition Coil Ass'y	1	Incl.47-53
3-47	283730	Coil	1	
3-48	261072	Cap	1	
3-49	283731	Tube	1	
3-50	283732	Spark Plug Wire Ass'y	1	Incl.51-53
3-51	283733	Spark Plug Wire	1	
3-52	261075	Connector	1	
3-53	261074	Plug Boot	1	
3-54	261076	Woodruff Key	1	3x10
3-55	261417	Nut,Rotor	1	M8
3-56	280381	Spacer	2	
3-57	261256	Cap Screw	2	M4x25
3-58	288264	Spark Plug	1	NGK BPMR8Y
3-59	261772	Lead	1	
3-60	268044	Lead	1	
3-61	269189	Grommet	1	
3-62	283476	Recoil Starter Ass'y	1	Incl.63-73
3-63	283477	Recoil Ass'y	1	Incl.64-72
3-64	283504	Reel	1	
3-65	283505	Cam Plate	1	
3-66	283506	Spring	1	
3-67	280931	Spiral Spring	1	
3-68	267213	Screw	1	
3-69	283578	Stater Rope Ass'y	1	Incl.70-72
3-70	283579	Stater Rope	1	
3-71	261725	Starter Grip	1	
3-72	283511	Rope Stopper	1	
3-73	283575	Starter Pawl Ass'y	1	
3-74	284698	Adapter Ass'y	1	
3-75	283391	Cap Screw	2	M4x20
3-76	265726	Cap Screw	4	M4x16
3-77	282096	Cap Screw	1	M4x16WSW
3-78	267561	Label	1	
3-79	288353	Label	1	
3-80	265694	Label	1	

4. BC2621H-RS-02  
 CARBURETOR, FUEL TANK















Ref. No.	Part No.	Part Name	Q'ty	Remarks
4-1	286259	Carburetor Ass'y	1	Incl.2-18 New gasket required
4-2	264155	Pump Body	1	
4-3	262991	Purge Body	1	
4-4	262992	Cover Plate	1	
4-5	261874	Primer Bulb	1	
4-6	283905	Diaphragm, Meterring	1	
4-7	262993	Gasket	1	
4-8	262994	Diaphragm,Fuel Pump	1	
4-9	282576	Gasket	1	
4-10	281487	Main Jet	1	#37
4-11	261871	O-Ring	1	
4-12	261876	E-Ring	1	
4-13	261658	Swivel	1	
4-14	261875	Screw	2	
4-15	264677	Bracket	1	
4-16	261657	Packing	1	
4-17	262996	Screw	4	
4-18	264678	Washer	1	
4-19	281441	Stand	1	
4-20	261352	Label	1	Choke
4-21	269762	Gasket	1	
4-22	268055	Air Filter Case Ass'y	1	Incl.23-26
4-23	268056	Air Filter Case	1	
4-24	268057	Valve	1	
4-25	268157	Sleeve	1	5.5x7.1x6L
4-26	268412	Sleeve	1	5.5x7.1x6.6L
4-27	263345	Packing	1	7.2x11xt1.3
4-28	263942	Washer	1	7.2x12xt0.15
4-29	263815	Stay	1	
4-30	264016	Cap Screw	2	M5x60
4-31	265026	Screen	1	
4-32	265027	Foam Element	1	
4-33	268058	Air Filter Cover Ass'y	1	Incl.34-36
4-34	268059	Air Filter Cover	1	
4-35	281438	Knob	1	
4-36	261734	Snap Ring	1	#5
4-37	284954	Fuel Tank Ass'y	1	Incl.38-48
4-38	281439	Fuel Tank	1	
4-39	281564	Fuel Tank Cap Ass'y	1	Incl.40
4-40	269377	Gasket	1	
4-41	282538	Fuel Pipe Pick-up Ass'y	1	Incl.42-48
4-42	282539	Fuel Pipe Ass'y	1	Incl.43-46
4-43	268065	Grommet	1	
4-44	261690	Fuel Pipe	1	160L
4-45	261590	Breather	1	

4. BC2621H-RS-02  
 CARBURETOR, FUEL TANK



Ref. No.	Part No.	Part Name	Q'ty	Remarks
4-46	261117	Clip	1	
4-47	264653	Filter Ass'y	1	
4-48	261117	Clip	1	
4-49	261117	Clip	1	
4-50	281714	Cap Screw	2	M5x20
4-51	281715	Cap Screw	1	M5x20

5. BC2621H-RS-02  
ACCESSORIES



Ref. No.	Part No.	Part Name	Q'ty	Remarks
5-1	210418	Box Spanner	1	13x19x(+)
5-2	022865	Double-ended Wrench	1	8x10
5-3	210181	Lever Handle	1	3.5x170L
5-4	220534	Blade Cover	1	
5-5	210179	Mowing Blade	1	230x4
5-6	232226	Semi-Auto Head (L)	1	
5-7	233336	Instruction Manual	1	RU/RO/PL
5-8	523779	Parts List	1	BC2621H-RS-02
5-9	219432	Wrench	1	4mm
5-10	219433	Wrench	1	5mm
5-11	234954	Colgate Tube	1	60L
5-12	234955	Band	1	3.4x145L