

PARTS LIST

TPP2630

CONTENTS

1. MAIN BODY	1 ~ 2
2. PRUNER HEAD	3 ~ 4
3. ENGINE	5 ~ 8
4. CARBURETOR, FUEL TANK	9 ~ 10
5. ACCESSORIES	11 ~ 12


2016. 12.



MARUYAMA


P/N 524201-2

1. TPP2630
MAIN BODY




Ref. No.	Part No.	Part Name	Q'ty	Remarks
1-1	364588	TPP2630	1	
1-2	224201	Clutch Case Ass'y	1	Incl.3-11
1-3	214592	Bearing Case	1	
1-4	214161	Bearing	2	#6000ZZ
1-5	054676	Snap Ring	1	#26
1-6	560309	Buffer	1	
1-7	214163	Washer	1	
1-8	092033	Screw	4	M5x15
1-9	214593	Driveshaft Tube Adapter	1	
1-10	220551	Clutch Drum	1	
1-11	014210	Snap Ring	1	#10
1-12	261246	Cap Screw	1	M5x25
1-13	235078	Throttle Trigger	1	
1-14	234694	Hanging Bracket Ass'y	1	Incl.15,16
1-15	234702	Cap Screw	1	M5x20
1-16	126993	Nut	1	M5
1-17	237254	Telescopic Pipe Ass'y	1	Incl.18-36
1-18	237574	Guide Pipe Ass'y	1	
1-19	237575	Drive Shaft	1	
1-20	237576	Set Collar	1	
1-21	237577	Cap Screw	1	M5x6
1-22	055186	Snap Ring	1	#12
1-23	237578	Bush Holder	5	
1-24	237579	Drive Bush	4	
1-25	237580	Spring	5	
1-26	233364	Screw	1	4x8
1-27	237581	Main Pipe Ass'y	1	
1-28	237582	Slide Holder	1	
1-29	237583	Sleeve	1	
1-30	237584	Slide Holder Washer	1	
1-31	237585	Cushion Tube	1	
1-32	237586	Knob	1	
1-33	237587	Bolt	1	M8x40
1-34	237588	Washer	1	8.7x17.6x1.6
1-35	237589	Cap Screw	1	M6x25
1-36	237590	Cap Screw	1	M5x10
1-37	238160	Label	1	TPP2630
1-38	238749	Label	1	
1-39	231264	Label	1	111dBA
1-40	261250	Cap Screw	4	M5x20
1-41	220533	Hanging Strap Ass'y	1	Incl.42
1-42	231657	Hook	1	

2. TPP2630
PRUNER HEAD




Ref. No.	Part No.	Part Name	Q'ty	Remarks
2-1	234082	Pruner Head Ass'y	1	Incl.2-34
2-2	231855	Gearcase A	1	
2-3	227990	Bearing	1	#608
2-4	231856	Gear Shaft	1	
2-5	231857	Gear	1	
2-6	231858	Worm Wheel	1	
2-7	231859	Pinion Shaft	1	
2-8	227992	Bearing	1	#609
2-9	227993	Bearing	1	#609Z
2-10	228477	Snap Ring	1	#9
2-11	140270	Snap Ring	1	#24
2-12	231860	Oil Pump	1	
2-13	231861	Seal	1	
2-14	231862	Screw	2	
2-15	231863	Pipe, Oil	1	
2-16	231864	Strainer	1	
2-17	234084	Gearcase B	1	
2-18	227991	Bearing	1	#6001DDU
2-19	231866	Sprocket	1	
2-20	231867	Washer	1	
2-21	231868	Bolt	1	M6x15
2-22	125588	Bolt	1	M6x30
2-23	234085	Screw	1	M4x30
2-24	231870	Adjuster	1	
2-25	231871	Bolt	4	M5x12
2-26	234086	Oil Tank Ass'y	1	Incl.27
2-27	231873	Breather	1	
2-28	231874	Tank Cap Ass'y	1	
2-29	092580	Bolt	2	M5x12
2-30	231875	Chain Cover Comp	1	
2-31	126756	Nut	1	M6
2-32	089819	Bolt	1	M6x8
2-33	261246	Cap Screw	1	M5x25
2-34	215993	Cap Screw	1	M5x10
2-35	234087	Chain Cover	1	
2-36	234088	Guide Bar	1	
2-37	289536	Chain	1	

3. TPP2630 ENGINE




Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-1	859888	Engine	1	EE262/03
3-2	273153	Cylinder	1	
3-3	282330	Gasket	1	
3-4	261250	Cap Screw	4	M5x20
3-5	282579	Insulator	1	
3-6	267049	Gasket	1	
3-7	269826	Screw	2	M5x25
3-8	276315	Muffler Ass'y	1	
3-9	266402	Cap Screw	2	M5x55
3-10	273147	Gasket	1	
3-11	273618	Under Cover	1	
3-12	269827	Screw	1	M5x16
3-13	276319	Top Cover	1	
3-14	280144	Tapping Screw	1	
3-15	273673	Crankcase	1	
3-16	280488	Bearing	2	PPL 6001
3-17	261492	Oil Seal	1	ISCD12287
3-18	261386	Oil Seal	1	ISCD12227
3-19	055185	Snap Ring	1	#28
3-20	261612	Cap Screw	3	M5x30
3-21	273155	Piston	1	
3-22	261496	Piston Ring	2	(2)Required
3-23	261497	Piston Pin	1	
3-24	261037	Bearing,Needle	1	KBK8x11x11.8x1
3-25	261576	Clip,Piston	2	
3-26	282323	Crankshaft/Conn.Rod Ass'y	1	
3-27	264503	Clutch Ass'y	1	Incl.28,29
3-28	264504	Clutch Shoe	2	(2)Required
3-29	263614	Spring,Clutch	1	
3-30	264505	Bolt	2	
3-31	261189	Washer	2	6x16.5x1.2
3-32	261777	Wave Washer	2	
3-33	283386	Fan Cover	1	
3-34	269831	Screw	4	M5x20
3-35	282692	Magneto Ass'y	1	Incl.36-42
3-36	261356	Rotor/Fan	1	
3-37	282693	Ignition Coil Ass'y	1	Incl.38-42
3-38	267401	Coil	1	
3-39	282694	Spark Plug Wire Ass'y	1	Incl.40-42
3-40	261074	Plug Boot	1	
3-41	261075	Connector	1	
3-42	282695	Spark Plug Wire	1	
3-43	261076	Woodruff Key	1	3x10
3-44	261417	Nut,Rotor	1	M8
3-45	280381	Spacer	2	

3. TPP2630
ENGINE











Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-46	261256	Cap Screw	2	M4x25
3-47	288264	Spark Plug	1	BPMR8Y
3-48	267492	Lead	1	130L
3-49	282880	Wire, Lead	1	
3-50	282404	Recoil Starter Ass'y	1	Incl.51-60
3-51	282405	Recoil Ass'y	1	Incl.52-59
3-52	283411	Reel	1	
3-53	283412	Cam Plate	1	
3-54	280930	Spring	1	
3-55	280931	Spiral Spring	1	
3-56	267213	Screw	1	
3-57	280932	Starter Rope Ass'y	1	Incl.58,59
3-58	280933	Starter Rope	1	
3-59	267219	Starter Grip	1	
3-60	280934	Starter Pawl Ass'y	1	
3-61	280489	Screw	2	M4x20
3-62	269833	Screw	1	M4x16
3-63	276736	Label	1	
3-64	284587	Label	1	
3-65	286122	Label	1	MARUYAMA

4. TPP2630
 CARBURETOR, FUEL TANK



Ref. No.	Part No.	Part Name	Q'ty	Remarks
4-1	276328	Carburetor Ass'y	1	Incl.2-15
4-2	281597	Pump Body	1	
4-3	262991	Purge Body	1	
4-4	262992	Cover Plate	1	
4-5	261874	Primer Bulb	1	
4-6	283905	Diaphragm, Meterring	1	
4-7	262993	Gasket	1	
4-8	262994	Diaphragm,Fuel Pump	1	
4-9	282576	Gasket	1	
4-10	285030	Main Jet	1	
4-11	261871	O-Ring	1	
4-12	261876	E-Ring	1	
4-13	261658	Swivel	1	
4-14	264682	Screw	2	
4-15	262996	Screw	4	
4-16	261864	Gasket	1	
4-17	289048	Case Ass'y	1	Incl.18-24
4-18	269050	Case Body	1	
4-19	289019	Valve	1	
4-20	284803	Lever	1	
4-21	284816	Washer	1	6.4x11x0.15
4-22	269032	Screw	1	
4-23	126993	Nut	1	M5
4-24	269051	Sleeve	2	
4-25	269030	Element	1	
4-26	281777	Screw	2	M5x55
4-27	269580	Cleaner Cover	1	
4-28	269031	Screw	1	M5x12
4-29	276310	Fuel Tank Ass'y	1	Incl.30-40
4-30	273467	Fuel Tank	1	
4-31	275306	Fuel Tank Cap Ass'y	1	Incl.32
4-32	274875	Gasket	1	
4-33	261696	Breather Ass'y	1	
4-34	265752	Fuel Pipe Pick-up Ass'y	1	Incl.35-40
4-35	264031	Fuel Pipe Ass'y	1	Incl.36-38
4-36	261115	Grommet	1	
4-37	261690	Fuel Pipe	1	160L
4-38	263038	Return Pipe	1	3x6x85L
4-39	264653	Filter Ass'y	1	
4-40	261117	Clip	1	
4-41	261117	Clip	1	
4-42	269828	Screw	2	M5x16
4-43	281208	Screw	1	M5x16

5. TPP2630
ACCESSORIES



Ref. No.	Part No.	Part Name	Q'ty	Remarks
5-1	219968	Box Spanner	1	10x19x(-)
5-2	219432	Wrench	1	4mm
5-3	234954	Colgate Tube	1	60L
5-4	234955	Band	1	3.4x145L
5-5	238164	Instruction Manual	1	GB/IT/FR
5-6	238165	Instruction Manual	1	ES/PT/DE
5-7	238166	Instruction Manual	1	GR/PL/RO
5-8	238167	Instruction Manual	1	NL/HR
5-9	524201	Parts List	1	TPP2630